

ASSEMBLY:

REMOVE THE PARTS FOR 1 BOX AT A TIME. THE TOP (BOTTOM) OVERLAPS THE SIDES. THE ENDS FIT INTO THE END. THERE ARE PARTS FOR TWO #7 BOXES. PAINT USING A WOOD STAIN COLOR SUCH AS FLOQUIL'S MAPLE.

BOX #	SIZE (HO Scale)	PART #	USAGE
1	2X4X2	8	SIDE
		9	TOP
		18	END
2	4X4X2	10	SIDE
		5	TOP
		11	END
3	4X4X4	7	SIDE
		6	TOP
		4	END
4	3X4X6	13	SIDE
		23	TOP
		21	END
5	3X3X6	12	SIDE
		24	TOP
		22	END
6	8X4X4	1	SIDE
		2	TOP
		3	END
7	2X2X2	14,17	SIDE
		15,16	TOP
		19,20	END

8

9

10

11

5

6

7

2

4

1

3

21

23

24

22

19

20

14

15

16

17

18

12

13